

Filter for Water Inter

It is installed at the water inlet to filter out potential dirt and debris from the main water line.



